



6110 First-Aid Kit

The following First-Aid Kit list outlines the most critical and/or most common replacement parts, that we feel would be good to keep at your farm. MSRP: \$2,216.94

Part Number	Qty	Description	Special Notes or Instructions
10003	2	Handhole Gasket 3 x 4	
10082	1	Isuzu Engine Oil Filter	
10083	1	Isuzu Engine Fuel Filter	
10084	1	Outer Engine Air Filter	
10085	1	Inner Engine Air Filter	
10090	1	In-Line Engine Fuel Filter	
10340	1	Control Relay 12VDC Coil	
10344 (11040)	1	Boiler Water Level Sensor Kit (Boiler Water Level Sensor, Sensor Only)	The 10344 must be used if the machine has not already been converted to the 11040-Boiler Water Level Sensor. The 10344 Kit contains 1 - 11040.
10350	1	Steam Pressure Sensor -14.7 to 30 PSI	
10363	1	Steam/Feedwater/Blowdown Actuator, EH2	
10371	1	Fuel/Supply Water Level Sensor, 0-100" WC	
10586	1	Pump Seal Kit 408 Deg.	
10644	1	O-Ring for UV Flame Detector	
10726	4	Needle Roller Bearing 5/16"	
10658	1	Fuse 0.5 Amp 5pk	
10290	1	Fuse 1.5 Amp 5pk	
10291	1	Fuse 2 Amp 5pk	
10292	1	Fuse 5 Amp 5pk	
10293	1	Fuse 15 Amp 5pk	



6210 First-Aid Kit

The following First-Aid Kit list outlines the most critical and/or most common replacement parts, that we feel would be good to keep at your farm. MSRP: \$2,785.17

Part Number	Qty	Description	Special Notes or Instructions
10003	2	Handhole Gasket 3 x 4	
10082	1	Isuzu Engine Oil Filter	
10083	1	Isuzu Engine Fuel Filter	
10084	1	Outer Engine Air Filter	
10085	1	Inner Engine Air Filter	
10090	1	In-Line Engine Fuel Filter	
10340	1	Control Relay 12VDC Coil	
10344 (11040)	1	Boiler Water Level Sensor Kit (Boiler Water Level Sensor, Sensor Only)	The 10344 must be used if the machine has not already been converted to the 11040-Boiler Water Level Sensor. The 10344 Kit contains 1 - 11040.
10350	1	Steam Pressure Sensor -14.7 to 30 PSI	
10363	1	Steam/Feedwater/Blowdown Actuator, EH2	
10371	1	Fuel/Supply Water Level Sensor, 0-100" WC	
10586	1	Pump Seal Kit 408 Deg.	
10657	1	Louver Actuator, EH3	
10658	1	Fuse 0.5 Amp 5pk	
10290	1	Fuse 1.5 Amp 5pk	
10291	1	Fuse 2 Amp 5pk	
10292	1	Fuse 5 Amp 5pk	
10293	1	Fuse 15 Amp 5pk	